## **GASTROINTESTINAL PATHOLOGY GROSSING GUIDELINES**

**Specimen Type**: END STOMA

## **Procedure:**

1. Measure the length and diameter of bowel.

- 2. Measure the location (distance from the closest bowel margin) and diameter of stoma opening.
- 3. Describe the presence or absence of skin at stoma opening, and the width of skin if present.

## **Gross Template:**

Labeled with the patient's name (\*\*\*), medical record number (\*\*\*), designated \*\*\*, and received [fresh/in formalin] is an [intact, disrupted] end ileostomy. The bowel measures \*\*\* cm in length x \*\*\* cm in diameter. There is a \*\*\* cm stomal diameter. Mesenteric/pericolic fat extends up to \*\*\* cm from the bowel wall.

The serosa is remarkable for [describe adhesions, plaques, full-thickness defects or is smooth, tan, glistening, and unremarkable]. There [is/ is no] skin present at the stoma site (measuring \*\*\* cm in width, if present). Mucosa at the stoma site is [red, granular, hemorrhagic, ulcerated] and extends up to \*\*\* cm above the surrounding tissue. The remaining mucosa is [pink-tan, red, granular, hemorrhagic ulcerated]. Representative sections are submitted.

**Cassette Submission:** 1-2 cassettes (additional cassette(s) if necessary to demonstrate pathology)

- Stapled resection margin, shave
- Unremarkable bowel in relation to stoma and skin, if present